

Star Trac Pro-Series Treadmills Pro-S, Pro and Pro-Elite

Preventative Maintenance

Star Trac and Blue Fitness strongly recommend performing regular preventive maintenance on your **STAR TRAC S SERIES TREADMILL**. Without regularly scheduled maintenance, normal wear and tear may cause cumulative effects, such as misalignment or premature wear. This may result in downtime.

Any unusual symptoms, such as display codes and blown circuit breakers, should be reported to Blue Fitness on (09) 845 0035 or via the website www.bluefitness.co.nz and Product Support.

DAILY MAINTENANCE

- Remove excessive accumulations of dust, dirt, and other substances by using a clean soft cloth and a non-abrasive liquid cleaner.
- Wipe down the display board, handrails, shroud and heart rate grips.

NOTE: DO NOT spray the cleaner directly onto the display board or heart rate grips and do not use liquid cleaner under the running belt.

- To ensure the longevity of the running belt, clean under the running belt with a soft, dry cloth.
 - To clean, slide the cloth between the running belt and deck from one side of the frame to the other (you may need a ruler or similar tool to slide the towel under the belt), then, holding the edges of the cloth, pull the cloth from the head-roller down to the tail-roller.
- ***NOTE: DO NOT clean the running belt by activating the treadmill***
- Inspect the running belt for alignment and tension. Do not tighten the running belt every day. If you notice slipping, contact Product Support as described below.
- Ensure the power cord is not under the treadmill and is positioned away from the elevation screws. This will prevent the power cord from being pinched or from binding up the elevation screws.

WEEKLY MAINTENANCE

- Vacuum the floor under and around the treadmill. Do so with the treadmill at its maximum elevation or moved to another spot.

NOTE: Take care not to damage the power cord while vacuuming.

- Inspect the inside surface of the running belt and the top surface of the running deck for unusual wear.
- Check the belt for a “glazed” condition (a smooth almost melted appearance). If the running belt appears glazed contact Blue Fitness via Product Support as described below
- Inspect the display and handrail screws for security, and retighten if necessary.
- Inspect the display panel/keypad for wear.

BI-WEEKLY MAINTENANCE

WARNING: To prevent personal injury, always turn the treadmill off and unplug the power cord before performing maintenance inside the motor compartment.

- Remove the motor shroud and vacuum around the motor and its ventilation holes. Avoid bumping or damaging parts normally protected by the shroud.

MONTHLY MAINTENANCE

- Wipe the elevation screws down with a clean dry cloth and coat them with silicon lubricant spray to prevent rust accumulation.